






1. INSPECT CHECK DAMS AFTER EACH STORM EVENT TO ENSURE STRUCTURAL INTEGRITY.
2. THE CENTER OF THE CHECK DAM SHOULD ALWAYS BE LOWER THAN THE GROUND ELEVATION @ THE EDGES.
3. WHEN SEDIMENT HAS REACHED 1/2 THE ORIGINAL DAM (MEASURED @ THE CENTER) REMOVE ACCUMULATED SEDIMENT FROM THE UPSTREAM SIDE OF THE DAM.
4. WHEN CHECK DAMS ARE REMOVED, CARE SHOULD BE TAKEN TO REMOVE ALL DAM MATERIALS.
5. USE PERMANENT VEGETATION TO STABILIZE, SOD, OR QUICK ESTABLISH SEED MIXES.
6. IN HIGHLY ERODIBLE SOILS EROSION CONTROL BLANKET SHALL BE PLACED 2' UPSTREAM AND 2' DOWNSTREAM OF THE CHECK DAM.

NOTE: SEE SWPPP PLANS FOR LOCATION OF CHECK DAM(S).



CHECK DAMS IN SWALE



ROCK CHECK DAM DETAIL (CD)

NO SCALE